



## Usage of Shims



For making the best adjustment in case the tiles having small differences in their thickness the use of shims (1 or 2 mm) is advisable.

